


# QUICK USER GUIDE 130 STRAIGHT



This is a quick start reference guide to help get you started using your Acorn 130 straight stairlift.

It is important for your safety that you study the User Manual to completely familiarise yourself with your stairlift.




## KEEPING LIFT ON

- 1 Key must always be kept in the on position as shown.
- 2 Switch must always be kept in the on position as shown.






**IMPORTANT - THE SWITCH SHOULD REMAIN ON WHILE THE LIFT IS PARKED ON A CHARGE POINT.**



**IMPORTANT - SEAT BELT MUST BE WORN DURING OPERATION.**





## SEAT BELT

- 1 Retract the seatbelt and pull over lap.
- 2 Push seatbelt into the buckle until it clicks.



## OPERATING THE LIFT

- 1 Press the switch towards the stairs to go up.
- 2 Press the switch away from the stairs to go down.





**REMINDER - THERE IS A 2 SECOND DELAY ONCE THE TOGGLE OR REMOTE IS PRESSED BEFORE THE LIFT STARTS TO MOVE. BOTH ARMS MUST BE COMPLETELY DOWN FOR THE STAIRLIFT TO OPERATE.**

**IMPORTANT - MAX WEIGHT USED ON LIFT IS 300 LBS. AND 350 LBS. ON HD MODEL. EXCEEDING WEIGHT LIMIT CAN RESULT IN SERIOUS INJURY.**

## REMOTE CONTROLS




- 1 Press the up arrow for the lift to go up.
- 2 Press the switch away from the stairs to go down.



## SWIVEL SEAT

At the top of the stairs push down on the lever to swivel the seat. Seat will lock at 45° and 90° when handle is released.

The seat must be swiveled back into position to operate.



**REMINDER - MAKE SURE THE SEAT IS LOCKED INTO POSITION FACING AWAY FROM THE STAIRCASE BEFORE GETTING ON OR OFF THE STAIRLIFT.**

## IN CASE OF UNEXPECTED STOP

*\*In the unlikely event that a problem should occur:*

- 1 When home alone using the stairlift we recommend that you carry a cell phone and alert others if you need help.
- 2 Remain calm on the stairlift making sure that both arm rests are down.
- 3 It is a good practice to ask someone else to help you troubleshoot.
- 4 Release the direction controller on the arm rest and press again in the **DOWN** direction.
- 5 If you must disembark for any reason: turn the seat, depressing the seat swivel lever allowing the lift to face the staircase. Release handle and lock the seat in place for a safe exit.

**IF THE STAIRLIFT FAILS TO OPERATE, PLEASE REMAIN CALM AND ALERT OTHERS BEFORE ATTEMPTING TO DISEMBARK THE STAIRLIFT.**

### IMPORTANT INFORMATION FOR USERS WITH A MANUAL HINGE


Using the remote control, move the lift up to an intermediate charge point if fitted or the top charge point. Once completed, manually lift the hinge to allow access through the doorway that was obstructed.

It is important that the stairlift is moved to the nearest charge point to ensure battery drain does not occur. Images shown for illustrative purposes only and may change.

# QUICK USER GUIDE 180 CURVED



This is a quick start reference guide to help get you started using your Acorn 180 curved stairlift.

**It is important for your safety that you study the User Manual to completely familiarise yourself with your stairlift.**



## TURNING THE LIFT ON



- 1 Key must always be kept in the on position as shown.
- 2 Switch must always be kept in the on position as shown.



## IMPORTANT - SEAT BELT MUST BE WORN DURING OPERATION.


### SEAT BELT

- 1 Retract the seatbelt and pull over lap.
- 2 Push seatbelt into the buckle until it clicks.



## OPERATING THE LIFT

- 1 Press the switch towards the stairs to go up.
- 2 Press the switch away from the stairs to go down.





**REMINDER - THERE IS A 2 SECOND DELAY ONCE THE TOGGLE OR REMOTE IS PRESSED BEFORE THE LIFT STARTS TO MOVE. BOTH ARMS MUST BE COMPLETELY DOWN FOR THE STAIRLIFT TO OPERATE.**

**IMPORTANT - MAX WEIGHT USED ON LIFT IS 266 LBS. EXCEEDING WEIGHT LIMIT CAN RESULT IN SERIOUS INJURY.**

## REMOTE CONTROLS


- 1 Press the up arrow for the lift to go up.
- 2 Press the down arrow for the lift to go down.



## SWIVEL SEAT

At the top of the stairs push down on the lever to swivel the seat. Seat will lock at 45° and 88° when handle is released.

The seat must be swiveled back into position to operate.



**REMINDER - MAKE SURE THE SEAT IS LOCKED INTO POSITION FACING AWAY FROM THE STAIRCASE BEFORE GETTING ON OR OFF THE STAIRLIFT.**

## IN CASE OF UNEXPECTED STOP

*\*In the unlikely event that a problem should occur:*

- 1 When home alone using the stairlift we recommend that you carry a cell phone and alert others if you need help.
- 2 Remain calm on the stairlift making sure that both arm rests are down.
- 3 It is a good practice to ask someone else to help you troubleshoot.
- 4 Release the direction controller on the arm rest and press again in the **DOWN** direction.
- 5 If you must disembark for any reason: turn the seat, depressing the seat swivel lever allowing the lift to face the staircase. Release handle and lock the seat in place for a safe exit.

**IF THE STAIRLIFT FAILS TO OPERATE, PLEASE REMAIN CALM AND ALERT OTHERS BEFORE ATTEMPTING TO DISEMBARK THE STAIRLIFT.**

### IMPORTANT INFORMATION FOR USERS WITH A MANUAL HINGE

Using either the arm control or remote control will start the lift in motion. When the lift reaches or leaves the programmed hinge zone the stairlift will stop and the powered hinge will automatically be raised or lowered at the bottom of the staircase. This will allow the user to operate the hinge whilst in a line of sight. Once you are finished using the stairlift; pressing the up button on the remote headset will automatically run the lift to either, an intermediate charge point if fitted or the top of the charge point.

**It is important that the stairlift is moved to the nearest charge point to ensure battery drain does not occur. Images shown for illustrative purposes only and may change.**

